



CONSOLE VAULT®

INNOVATIVE SECURITY SOLUTIONS

(800) 878-1369

www.consolevault.com

2014 - 2021 — Toyota Highlander

Instruction Sheet (1071)



Installation Steps:

- 1) If applicable, reset the combination lock before beginning installation.
- 2) Remove all contents from the center console.
- 3) Open both sliding doors on the console.
- 4) Close and lock the in-vehicle safe then fold the hinged sections into the underside of the door (4).
- 5) Insert in-vehicle safe diagonally into console (5A) and prop safe up against the driver's side of the console (5B).
- 6) Lift in-vehicle safe up by the finger pull (bracing with other hand as necessary) over the ledge inside console (6) then lower safe such that it is resting on both ledges.
- 7) Unlock and open the door on the in-vehicle safe then push hinged sections outward until they make contact with the front and back of the console (7).
- 8) Insert bottom plate of in-vehicle safe through front side of door opening (8A) and gently lower it to the bottom of the console (8B).
- 9) Position bottom plate of in-vehicle safe such that the half slots line up with all threaded studs on the hinged sections (9). **(Note: The hinged sections may need to be pushed out again)**

Step 4



Step 5A



Step 5B



Step 6



Step 7



Step 8A



Step 8B



Step 9





CONSOLE VAULT®
INNOVATIVE SECURITY SOLUTIONS

(800) 878-1369

www.consolevault.com

2014 - 2021 — Toyota Highlander Instruction Sheet (1071)



Installation Steps:

- 10) Hand start (4X) flange nuts on the threaded studs of the hinged sections of the in-vehicle safe (10A) then tighten with a 1/2" socket wrench until they come to a hard stop (10B). **(WARNING! Do not over tighten, as this may cause damage to the threaded studs on the safe.)**
- 11) Hand start (2X) self-drilling screws into the hinged sections of the in-vehicle safe (11A) then tighten with a 7/16" socket wrench until they come to a hard stop (11B). **(WARNING! Do not over tighten, as this may cause damage to the threaded features on the safe.)**
- 12) Insert pad into in-vehicle safe (12).
- 13) The installation is now complete!

Step 10A



Step 10B



Step 11A



Step 11B



Step 12

